

BREAK-IN INSPECTION

Procedures are detailed in *PERIODIC MAINTENANCE PROCEDURES* subsection.

BREAK-IN INSPECTION
Adjust oil injection pump (600 and 800R Power TEK models)
Inspect spark plugs (600 and 800R Power TEK models)
Inspect exhaust system and check for leaks
Check coolant level
Inspect fuel lines and connections
Inspect throttle cable
Inspect drive belt
Visually inspect drive pulley
Tighten drive pulley retaining screw to specified torque
Inspect driven pulley
Adjust and align track
Change chaincase oil
Adjust drive chain
Check brake fluid level
Inspect brake hose, pads and disk
Inspect steering mechanism
Inspect skis and runners
Inspect front suspension
Inspect rear suspension and slider shoes